

Panasonic Grid-Eye Evaluation Kit PAN-9520 EVB & Grid-Eye Shield

How to set up the Evaluation Kit




Please install "Grid Al Express" on your PC.




2 Double click "Grid Al Express" icon.




Please connect upper side USB connector of Grid-Eye evaluation kit and your PC USB connector.



Now you can see this initial picture on your PC.



Open "device manager" and check for "ports" and then "USB Serial Device".




Please click "Connection setting window" button (upper right corner).



Please select "COM No" same as USB Serial Device ("COM No")



B Demonstration of Grid-Eye detection



Please swipe your hand slowly from left to right above the Grid-Eve sensor.



The Grid-Eye sensor will detect your hand and the shadow of your hand will become visible on your monitor.



Please refer to the user manual for other functions.
 Grid-Eye evaluation kit | Panasonic Industry Europe GmbH

- * In order to download the software, you need to have admin rights.
 ** Unplug and plug again the evaluation kit in case you don't see the driver.
- *** It requires to download .NET Microsoft Windows Runtime